

# SPK-Descale

## For automatic machines and equipment



Concentrated acid-based liquid for descaling industrial automatic dish & glasswasher machines.

- Highly effective multipurpose liquid.
- Suitable for removing limescale from a variety of kitchen equipment.
- Unperfumed & undyed.

### DISH & GLASSWASHING MACHINES

Switch off dosing pump. Fill machine with clean water. Prepare a 5% solution by pouring DESCALER into machine at a ratio of 2 L per 40 liters capacity. Leave for 2-3 minutes.

Switch on machine & circulate the solution for between 5-10 minutes. Drain the solution & refill with fresh water. Circulate the water for a further 3 minutes & drain. Air dry by leaving the machine door open. Switch on dosing pumps.

### DESCALING BAIN MARIES, BOILERS, TEA & COFFEE URNS:

Dilute 1:25 parts warm water (200 ml per 5 L / 7 x per 5 L).

Pour into vessel & allow to soak for 5 minutes. Drain solution, scrub surface with a stiff brush. Rinse thoroughly with clean water.

Descale on a regular basis to maintain efficiency of machine & extend the life of the heating element.

5l

Order Code: 25.70.705

Pack: 4 x 5 liter

Pallet: 60 Packs

### PRODUCT INFORMATION:

Appearance: Clear colorless liquid  
Odor: Unperfumed  
pH - undiluted: 0.15  
Shelf life: 3 years

### COMPOSITION:

Contains a blend of phosphoric acid, amphoteric & nonionic surfactants.

### BIODEGRADABILITY:

All surfactants used in Sparklean's products comply with the current European Regulations concerning biodegradability & protection of the environment.

### QUALITY ASSURANCE:

This product is manufactured in the U.A.E by  
sparklean



SPARKLEAN GLOBAL FOR DETERGENTS AND  
DISINFECTANTS MANUFACTURING L.L.C

www.sparkleanglobal.com | Tel: +97167314701 | mobile: +971544472285